

## THE BRACKET



### TOP TIP!

Before arranging the louvers onto the rail, use the wand to rotate the hooks so that they all face to the side. This will allow you to hook and position the louvers on easily and also ensures that the louvers will not tangle.

If you have any questions about your installation please contact us:

(02) 4954 7190 | [sales@lakeviewblinds.com.au](mailto:sales@lakeviewblinds.com.au)

### STEP 1.

#### POSITIONING THE BRACKETS

A bracket should be arranged at either side of the rail, 100mm away from the end.

Spare brackets should be dispersed uniformly along the width of the rail.

If you are working with top-fix brackets, the front edge of the bracket must be positioned at least 75mm away from the facing exterior. By following this guide it will ensure that the louvers pivot freely without touching the wall or the window surrounds.



### STEP 2.

#### FITTING THE BLIND

##### Option 1 - Face Fit Bracket

To fix the bracket to the wall use two screws on the facing exterior.

Position the back of the rail onto the hook of the bracket. Raise the front of the rail so it is positioned in line with the bracket and fix the front screw so that it is positioned into the front rim of the rail.

##### Option 2 – Top Fix Bracket

To fix the bracket to the wall use a single screw to attach to the above exterior.

Position the front rim of the rail onto the front lip of the bracket. Lift the back of the rail to meet the bracket and press securely upwards so that it clicks into place.

### TOP TIP!

Before arranging the louvers onto the rail, use the wand to rotate the hooks so that they all face to the side. This will allow you to hook and position the louvers on easily and also ensures that the louvers will not tangle.

If you have any questions about your installation please contact us:

(02) 4954 7190 | [sales@lakeviewblinds.com.au](mailto:sales@lakeviewblinds.com.au)